

CRYST RAMA



ASSEMBLY INSTRUCTION MODEL#2264-AG-LED




It can be mounted both vertically and horizontally.





HOW TO REPLACE LED: REMOVE METAL FRAME AND SCREWS TO REPLACE PREVIOUS LED.



Place the mounting plate over the outlet box and secure it with outlet box screws. Insert and tighten the anchor screws into the wall

4.Install backplate onto the mounting plate, and

5. Place the glass shade inside the metal frame


6.Install metal frame onto the backplate, and

secure with the mounting screws.

and secure it with the clips.

secure with the side screws.

anchors until snug.



WARNING: This product can expose you to Lead which is known to the state of California to cause cancer and/or birth defects or reproductive harm. For more information go to www.P65Warnings.ca.gov





ASSEMBLY INSTRUCTION MODEL#2264-AG-LED

Part Number

- Part Numbers
- A. (1)-Mounting hardware
- B. (1)-Mounting plate
- C. (1)-Backplate L23-5/8''xW4-1/2''xH3/4'' #XRF2264AGBKP23.625IN
- D. (4)-Mounting screw
- E. (1)-Glass shade #XRF2264LGLA23.75IN
- F. (4)-Side screw
- G. (1)-Metal frame

