




LIGHTING THE WAY FOR SIXTY YEARS

ASSEMBLY INSTRUCTION MODEL #1157-CH-CL-MWP



Crystal Sets

A. 126 Sets. (1)14mm + (1)AS9-2"

B. 1 Sets. (3)14mm + (1)AS8-50mm Ball

C. 8 Sets. (1)14mm + (1)Square + (1)AS9-2.5"

D. 8 Sets. (2)14mm + AS9-2"

E. 8 Piece. (8)14mm

F. 16 Sets. (2)14mm + (1)Square + AS9-2.5"

G. 8 Sets. (13)14mm H. 8 Sets. (8)14mm I. 8 Sets. (16)14mm J. 16 Sets. (21)14mm

K. 8 Sets. (7)14mm + AS9-2.5"

L. 8 Sets. (21)14mm

M. 8 Sets. (9)14mm + (1)Square + (2)14mm + AS9-2.5" N. 8 Sets. (1)14mm + (1) 4pin 14mm + (5)14mm + AS9-2.5" O. 8 Sets. (20)14mm + (1)Square + (2) 14mm + AS9-2.5" P. 16 Sets. (23)14mm

Q. 8 Sets. (1)14mm + (1)Square + (4)14mm + AS9-2.5"



Electrical Danger

Turn Power Off

All electrical components must be installed by a licensed electrician in accordance with the National Electric Code and the appropriate

local electrical codes.



You will need 20- Candelabra Base Bulb 40 Watts recommended 40 Watts Max. USE LED BULBS FOR EXTENDED USE

The fixture is Damp rated

HOW TO INSTALL:

Place the fixture parts on a soft cloth-covered platform before installation of fixture.

1. To install the 6"arms, slightly loosen each screw on the metal plate.

Pull a female plug through a hole in the upper metal plate.

Connect the male plug at the end of the upper arm with the female plug that was just pulled. Push the end of the arm with the metal tab through the hole until stopped by the metal tab (this should also push the wires and plugs back inside the metal plate).

Twist the metal tab counter-clock wise until both inserts lock onto the loose screws. Tighten the screw securing the arm in place. Repeat for all 6"arms.

- 2. Repeat Step 1 for the 10" and 15" arms. The 10" arms attaches on the middle tier and the 15" arms attaches on the bottom-most tier.
- 3. Thread the threaded pipe into the coupling at the bottom of Center Column Kit 2 then place the glass vase, check ring, metal washer, bobeche and metal washer in that order. Secure with the finial.
- 4. Screw the Center column kit 1 onto the center column kit 2.
- 5. Set the mounting hardware onto the beam.
- 6. Decide the desired hanging height and adjust the chain to the correct length.
- 7. Raise the fixture up and do the wire connection. Attach the canopy over the mounting nipple and secure with collar ring.
- 8. Dress the crystals as illustrated.


MARNING: This product can expose you to Lead, which is known to the State of California to cause cancer and/or birth defects or reproductive harm. For more information go to www.p65warnings.ca.gov






LIGHTING THE WAY FOR SIXTY YEARS

ASSEMBLY INSTRUCTION MODEL #1157-CH-CL-MWP



SAFETY CABLE INSTALLATION INSTRUCTIONS




IMPORTANT:

FOR A SAFE AND SECURE INSTALLATION, THESE FIXTURES MUST BE INSTALLED BY MEANS OF SUPPORTS THAT ARE INDEPENDENT OF THE OUTLET BOX.

SUGGESTED INSTALLATION:

- 1. Provide a 1/4 IPS pipe with one end securely mounted to a beam or a structural member. The other end should protrude through the center of the outlet, as shown.
- 2. Assemble the screw collar loop, nipple, hex nuts and hickey to center 1/4 IPS support pipe and adjust overall length to allow the collar ring to hold the canopy flush to the ceiling. When the adjustments have been completed secure the hex nut, as shown.
- 3. Use one quick link to connect fixture loop and the bottom of chain. Slide the screw collar ring over the upper end of the chain, through the (Finished side down). Then use another quick link to connect the collar loop and the top of chain.
- 4. Lace the fixture wires, ground wires and safety cable through the chain and screw collar loop, exiting through the side of HICKEY. Proceed to attach the FIXTURE GROUND WIRE to the HOUSE GROUND WIRE using wire connector. Using wire connectors, connect the HOUSE WHITE WIRE to the FIXTURE SUPPLY WIRE (WHITE OR RIBBED SIDE); connect the HOUSE BLACK (or RED) WIRE to the FIXTURE SUPPLY WIRE (BLACK or SMOOTH SIDE). Wrap all connectors with approved electrical tape. Wrap safety cable around outlet box brace and pull cable taut. Secure cable with the clamp and (2) set screws provided, as shown.
- 5. Push the CANOPY upward over the OUTLET BOX. Be sure that all wires are carefully tucked into the OUTLET BOX cavity. Secure canopy against ceiling by threading CANOPY LOCK RING onto the CANOPY LOOP. Tighten until snug.

***ATTENTION-If the use of the Mounting Bracket is the installation method being done, you will need an outlet box (not supplied) rated for 100lbs or more ***



NOTE:NEC CODE (314.24) requires that ceiling outlet boxes in the United States support up to 50 lbs. This fixture exceeds 50 lbs. and must be installed using an outlet box approved for up to 100 lbs. or independently of the existing outlet box. Installation hardware and instructions are provided for both.

MOUNTING TO A 100 lb. MAX. APPROVED OUTLET BOX.

- 1. Feed the Support cable from the fixture through the outlet box. Drill 3/16" diameter hole in outlet box if no other holes are available. Wrap safety cable around the structural member and pull cable taut. Secure cable with the clamp and (2) set screws provided.
- 2. Screw the threaded rod into the coupling until the threaded rod is flush with top of the coupling. Secure in place by tightening the sets screw.
- 3. Pass the threaded pipe through the mounting strap.
- 4. Thread screw collar loop onto the threaded rod until the threaded rod is flush with hole on lower side of screw collar loop.
- 5. Secure screw collar loop in place by tightening the hex nut.
- 6. Assemble the mounting strap to outlet box using screws provided with outlet box.
- 7. Use one quick link to connect fixture loop and the bottom of chain. Slide the screw collar ring over the upper end of the chain, through the (Finished side down). Then use another quick link to connect collar loop and the top of chain.
- 8. Lace the fixture wires, ground wires and safety cable through the chain and screw collar loop. Proceed to attach the FIXTURE GROUND WIRE to HOUSE GROUND WIRE using wire connector. Using wire connectors, connect the HOUSE WHITE WIRE to the FIXTURE SUPPLY WIRE (WHITE OR RIBBED SIDE); connect the HOUSE BLACK (or RED) WIRE to the FIXTURE SUPPLY WIRE (BLACK or SMOOTH SIDE). Wrap all connectors with approved electrical tape.
- 9. Push the CANOPY upward over the OUTLET BOX. Be sure that all wires are carefully tucked into the OUTLET BOX cavity. Secure canopy against ceiling by threading CANOPY LOCK RING onto the CANOPY LOOP. Tighten until snug.